

## Care and Cleaning


Your Air Conditioning Unit will work more efficiently if it is cleaned regularly. Here is our handy guide for you to keep up with regular cleaning in between services.

### FRONT PANEL

To remove front panel, slide the panel to either left or right and pull it towards you. This disconnects the rotation dowel on one side. Disconnect the other side in the same manner.

To remove Dirt: Wipe Clean with a soft clean soaked in water.

To re-attach the front panel, press the front panel at both sides and the centre.





**Air Filters:**

To remove: push the filter tab (located at the centre of each air filter) upwards a little then pull it down

Vacuum dust or wash filter.

Frequency: Monthly



STREAMER




**Air-Purifying Filter**

Vacuum Dust or replace Filter


Clean once every 6 months and replace every 3 Years

## Things to Consider


When cleaning your unit there are a few things that you will need to consider:

 If dirt cannot be vacuumed from filters, use lukewarm water and diluted detergent to wash the filter and then dry in the shade


 Do not wring the filters out; let them dry naturally

 Do not use water above 40°


 Do not use Benzine, gasoline, thinners or other volatile oils

 Do not use any polishing compounds

 Scrubbing brushes or other hard materials

 Only neutral detergent may be used when cleaning the panel

 Remotes can be cleaned with a soft cloth if dirty

 Do not touch the aluminium fins by bare hands at the time of dismounting or mounting the filter.

### Using your air con with dirty filters:

 Cannot deodorize the air

 Cannot clean the air



Results in poor cooling and heating